





401

РРЛ-401-001

*Позиционер плунжера 83
(62-402-2)*







PPI-401-001

Позиционер плунжера 83
(62-402-2)

Спецификация




№ поз.	Шифр	Наименование	Кол-во
--------	------	--------------	--------

Детали:




1	PPI-401-001-001	Проставка	1
2	PPI-401-001-002	Гильза	1
3	PPI-401-001-003	Втулка направляющая	1
4	PPI-401-001-004	Крышка	1
5	PPI-401-001-005	Стакан	1
6	PPI-401-001-006	Держатель пружины	1
7	PPI-401-001-007	Пружина	1
8	PPI-401-001-008	Проставка	1
9	PPI-401-001-009	Кольцо дистанционное	1
10	PPI-401-001-010	Полукольцо	2
11	PPI-401-001-011	Адаптер	1
12	PPI-401-017-006	Втулка	1

Стандартные изделия:




13	Винт 1/4"-20X1" DIN 913	2
14	Винт UNC3/8"-16x3" DIN 912	4
15	Винт UNC5/16"-18x1 1/2" DIN 912	3
16	Штифт ф 3x18 DIN 1481	1






Пружина
PPI-401-001-001





Стакан
PPI-401-001-005





Адаптер
PPI-401-001-011






Полукольцо
PPI-401-001-010






Кольцо дистанционное
PPI-401-001-009






Держатель пружины
PPI-401-001-006





Проставка
PPL-401-001-008





Проставка
PPL-401-001-001



Втулка направляющая
PPL-401-001-003



Крышка
PPL-401-001-004



Гильза
PPL-401-001-002