


401

PPI-401-001

*Позиционер плунжера 70
(62-402-2)*

Позиционер плунжера 70
(62-402-2)
PPL-401-001



401



PPL-401-001

Позиционер плунжера 70
(62-402-2)
PPL-401-001


401



PPL-401-001

Позиционер плунжера 70
(62-402-2)
PPL-401-001

401



PPL-401-001

Позиционер плунжера 70
(62-402-2)
PPI-401-001

401

PPI-401-001

Позиционер плунжера 70
(62-402-2)

Спецификация

№ поз.	Шифр	Наименование	Кол-во
--------	------	--------------	--------

Детали:

1	PPI-401-001-001	Проставка	1
2	PPI-401-001-002	Гильза	1
3	PPI-401-001-003	Втулка направляющая	1
4	PPI-401-001-004	Крышка	1
5	PPI-401-001-005	Стакан	1
6	PPI-401-001-006	Держатель пружины	1
7	PPI-401-001-007	Пружина	1
8	PPI-401-001-008	Проставка	1
9	PPI-401-001-009	Кольцо дистанционное	1
10	PPI-401-001-010	Полукольцо	2
11	PPI-401-001-011	Адаптер	1




Стандартные изделия:

12	Винт 1/4"-20X1" DIN 913	2
13	Винт UNC3/8"-16x3" DIN 912	4
14	Винт UNC5/16"-18x1 1/2" DIN 912	3
15	Штифт ф 3x18 DIN 1481	1




PPI-401-001

Позиционер плунжера 70
(62-402-2)
PPL-401-001




401



Пружина
PPL-401-001-001



Стакан
PPL-401-001-005





Адаптер
PPL-401-001-011



PPL-401-001

Позиционер плунжера 70
(62-402-2)
PPL-401-001



401



Полукольцо
PPL-401-001-010



Кольцо дистанционное
PPL-401-001-009






Держатель пружины
PPL-401-001-006




PPL-401-001

Позиционер плунжера 70
(62-402-2)
PPL-401-001




401



Проставка
PPL-401-001-008



Проставка
PPL-401-001-001





Втулка направляющая
PPL-401-001-003




PPL-401-001

Позиционер плунжера 70
(62-402-2)
PPL-401-001

401



Крышка
PPL-401-001-004



Гильза
PPL-401-001-002

PPL-401-001