




401

MX-401-002
TAKE OUT HEAD
(222994)


Take out head MX-401-002



Take out head MX-401-002






Take out head MX-401-002






Take out head MX-401-002

Спецификация




№ pos.	Code	Name	Qty
Parts			
1	33-020_06M	Holder	1
2	33-020_06П	Holder	1
3	222994-401-001-01	Fork	1
4	222994-401-001-02	Piston	1
5	222994-401-001-03	Stok	1
6	222994-401-001-04	Finger	1
7	222994-401-001-05	Finger	2
8	222994-401-001-06	Clevis	1
9	222994-401-001-07	Clevis	2
10	222994-401-001-08	Cylinder	1
11	222994-401-001-09	Bushing	1
12	222994-401-001-10	Ring	1
13	222994-401-001-11	Spring	1
Standard parts			
14	Spring washer B6-A4 DIN 127		1
15	Split pin DIN 94-3x20		3
16	Hexagon Flange Bolt M10x20 DIN 6921		2
17	O-ring 036-042-36-1-7 GOST 18829-73		1
18	Screw M5x25 DIN 912		2
19	Nut M5 DIN 985		2
20	Screw M6x40 DIN 912		1
21	O-ring 048-051-19-1-7 GOST 18829-73		2



1. Holder
33-020_06M






2. Holder
33-020_06M






3. Fork
MX-401-002-001



401





4. Piston
MX-401-002-002





5. Stok
MX-401-002-003





6. Finger
MX-401-002-004





6. Finger
MX-401-002-005





7. Clevis
MX-401-002-006





8. Clevis
MX-401-002-007





10. Cylinder
MX-401-002-008



11. Bushing
MX-401-002-009



12. Ring
MX-401-002-010



13. Spring
MX-401-002-011