




401

PPI-401-007

*Позиционер плунжера
(GPSM-MRN-401-70_000_00BB-VS)*





PPI-401-007

Позиционер плунжера
(GPSM-MRN-401-70_000_00BB-VS)

Спецификация


№ поз.	Шифр	Наименование	Кол-во
--------	------	--------------	--------

Детали:


1	PPI-401-006-004	Держатель пружины	1
2	PPI-401-007-001	Корпус картриджа	1
3	PPI-401-007-002	Гильза	1
4	PPI-401-007-003	Пружина	1
5	PPI-401-007-005	Упор	1
6	PPI-401-007-006	Пружина	1
7	PPI-401-007-007	Стакан	1
8	PPI-401-007-008	Кольцо	1
9	PPI-401-007-009	Втулка направляющая	1
10	PPI-401-007-010	Спец. винт	2
11	PPI-401-007-011	Кольцо	1

Стандартные изделия:



12	Винт UNC5/16"-18x1" DIN 912	2
13	Кольцо стопорное B 60 DIN 7993	1
14	Штифт Ф4x12 DIN 1481	2






Корпус картриджа
PPL-401-007-001






Упор
PPL-401-007-005






Держатель пружины
PPL-401-006-004





Пружина
PPL-401-007-003





Гильза
PPL-401-007-002





Спец. винт
PPL-401-007-010





Кольцо
PPL-401-007-008





Стакан
PPL-401-007-007



Пружина
PPL-401-007-006



Кольцо
PPI-401-007-011



Втулка направляющая
PPI-401-007-009