




401

MKO-GPS-401-001
DEFLECTOR ADJUSTER



Deflector adjuster MKO-GPS-401-001



Deflector adjuster
MKO-GPS-401-001






Deflector adjuster
MKO-GPS-401-001






Deflector adjuster MKO-GPS-401-001 Specification




№ pos.	Code	Name	Qty
Assemblies			
1	MKO-GPS-401-001-001	Main body	1
2	MKO-GPS-401-001-002	Cover	1
3	MKO-GPS-401-001-003	Cover	1
4	MKO-GPS-401-001-004	Screw	4
Parts			
5	MKO-GPS-401-001-005	Shaft	2
6	MKO-GPS-401-001-006	Screw	2
7	MKO-GPS-401-001-007	Screw	2
8	MKO-GPS-401-001-008	Bearing slide	4
9	MKO-GPS-401-001-009	Bearing slide	4
10	MKO-GPS-401-001-010	Bushing	6
11	MKO-GPS-401-001-012	Bushing	8
12	MKO-GPS-401-001-013	Retainer	2
13	MKO-GPS-401-001-015	Holder	2
14	MKO-GPS-401-001-016	Housing	4
15	MKO-GPS-401-001-017	Block	2
16	MKO-GPS-401-001-019	Knob	4
17	MKO-GPS-401-001-020	Retainer	2
18	MKO-GPS-401-001-021	Plate	2
19	MKO-GPS-401-001-034	Threaded bushing	2
20	MKO-GPS-401-001-035	Screw	2
21	MKO-GPS-401-001-036	Washer	2
Standard parts			
22	O-ring 030-034-25 GOST 9833-73		2
23	Lube nipple A-M10x1 DIN 71412		2
24	Spring pin 3x14 DIN 1481		4
25	Nut M6 DIN 934		12
26	Nut M8 DIN 934		4
27	Washer 4 DIN 125		2
28	Screw M3x5 ГОСТ 17473-80		8
29	Washer 6И DIN 125		4
30	Pin 2,5Гx14 DIN 1481		4
31	Washer 4И DIN 125		10
32	Screw M5x10 DIN 912		2
33	Screw M4x10 DIN 912		2
34	Screw M6x20 DIN 913		8
35	Screw M4x20 DIN 912		8






5. Shaft
MKO-GPS-401-001-005






6. Screw
MKO-GPS-401-001-006





7. Screw
MKO-GPS-401-001-007






8. Bearing slide
MKO-GPS-401-001-008






9. Bearing slide
MKO-GPS-401-001-009






10. Bushing
MKO-GPS-401-001-010






11. Bushing
MKO-GPS-401-001-012






12. Retainer
MKO-GPS-401-001-013






13. Holder
MKO-GPS-401-001-015






14. Housing
MKO-GPS-401-001-016






15. Block
MKO-GPS-401-001-017






16. Knob
MKO-GPS-401-001-019






17. Retainer
MKO-GPS-401-001-020





18. Plate
MKO-GPS-401-001-021



19. Threaded bushing
MKO-GPS-401-001-034






20. Screw
MKO-GPS-401-001-035






21. Washer
MKO-GPS-401-001-036




Assemblies





1. Main body
MKO-GPS-401-001-001



2. Cover
MKO-GPS-401-001-002



3. Cover
MKO-GPS-401-001-003



4. Screw
MKO-GPS-401-001-004