


401

*Cartridge /
Plunger Positioner 70
(A57-1070)*

Cartridge /
Plunger Positioner 70
(A57-1070)
PPL-401-020



401



PPL-401-020

Cartridge /
Plunger Positioner 70
(A57-1070)
PPl-401-020

401



PPl-401-020

Cartridge /
Plunger Positioner 70
(A57-1070)
PPL-401-020

401

PPL-401-020

Cartridge /
Plunger Positioner 70
(A57-1070)

Specification

Nº pos.	Code	Name	Qty
---------	------	------	-----



Parts:

1	PPL-401-020-001	Screw	2
2	PPL-401-020-002	Ring	1
3	PPL-401-020-003	Washer	2
4	PPL-401-020-004	Spring	1
5	PPL-401-020-005	Sleeve	1
6	PPL-401-020-006	Bushing	1
7	PPL-401-020-007	Bushing	1
8	PPL-401-020-008	Spring retainer	1
9	PPL-401-020-009	Casing	1
10	PPL-401-020-010	Cap	1
11	PPL-401-020-011	Semi-ring	2
12	PPL-401-020-012	Adapter	1




Standard parts:

13	Poppet spring M6 ГОСТ 3057-90	10
14	Screw M10x70 DIN 912	4
15	Screw M5x5 GOST 11074-93	1
16	Screw M5x8 DIN 912	6



PPL-401-020



Bushing
PPL-401-020-007




Screw
PPL-401-020-001





Ring
PPL-401-020-002


Cartridge /
Plunger Positioner 70
(A57-1070)
PPL-401-020



Bushing
PPL-401-020-006





Cap
PPL-401-020-010





Casing
PPL-401-020-009

Cartridge /
Plunger Positioner 70
(A57-1070)
PPl-401-020




401



Sleeve
PPl-401-020-005





Spring retainer
PPl-401-020-008




Adapter
PPl-401-020-012



PPl-401-020



Semi-ring
PPL-401-020-011



Washer
PPL-401-020-003



Spring
PPL-401-020-004