

401

PPl-401-038



*Cartridge /
Plunger Positioner 90
(KE-401-90_000-vs)*

401



Cartridge /
Plunger Positioner 90
(KE-401-90_000-vs)
PPl-401-038

401



PPl-401-038

Cartridge /
Plunger Positioner 90
(KE-401-90_000-vs)
PPL-401-038

401

PPL-401-038

Cartridge /
Plunger Positioner 90
(KE-401-90_000-vs)
Specification

Nº pos.	Code	Name	Qty
---------	------	------	-----

Parts:

1	PPL-401-005-002	Sleeve	1
2	PPL-401-005-003	Spring	1
3	PPL-401-005-004	Spring retainer	1
4	PPL-401-010-011	Adapter	1
5	PPL-401-038-001	Main body	1
6	PPL-401-038-002	Split ring	1
7	PPL-401-038-003	Ring adapter	1



Standard parts:

8	Screw UNC5/16"-18x2 1/4" DIN 912	2
9	Spring pin ϕ 4x12 DIN 1481	2


PPL-401-038

Cartridge /
Plunger Positioner 90
(KE-401-90_000-vs)
PPL-401-038


401



Main body
PPL-401-038-001






Spring retainer
PPL-401-005-004






Sleeve
PPL-401-005-002

Cartridge /
Plunger Positioner 90
(KE-401-90_000-vs)
PPL-401-038




401





Adapter
PPL-401-010-011



Split ring
PPL-401-038-002



Ring adapter
PPL-401-038-003



Spring
PPL-401-005-003