


401



*PPI-401-038*

*Позиционер плунжера 90  
(KE-401-90\_000-vs)*

Позиционер плунжера 90  
(KE-401-90\_000-vs)  
PPI-401-038

401





## PPI-401-038

Позиционер плунжера 90  
(KE-401-90\_000-vs)

### Спецификация



| № поз. | Шифр | Наименование | Кол-во |
|--------|------|--------------|--------|
|--------|------|--------------|--------|

#### Детали:


|   |                 |                   |   |
|---|-----------------|-------------------|---|
| 1 | PPI-401-005-002 | Стакан            | 1 |
| 2 | PPI-401-005-003 | Пружина           | 1 |
| 3 | PPI-401-005-004 | Держатель пружины | 1 |
| 4 | PPI-401-010-011 | Адаптер           | 1 |
| 5 | PPI-401-038-001 | Корпус картриджа  | 1 |
| 6 | PPI-401-038-002 | Полукольцо        | 1 |
| 7 | PPI-401-038-003 | Кольцо адаптера   | 1 |

#### Стандартные изделия:


|   |                                 |   |
|---|---------------------------------|---|
| 8 | Винт UNC5/16"-18x2 1/4" DIN 912 | 2 |
| 9 | Штифт ф4x12 DIN 1481            | 2 |



Корпус картриджа  
PPL-401-038-001






Держатель пружины  
PPL-401-005-004






Стакан  
PPL-401-005-002

Позиционер плунжера 90  
(KE-401-90\_000-vs)  
PPL-401-038




401






Адаптер  
PPL-401-010-011



Полукольцо  
PPL-401-038-002



Кольцо адаптера  
PPL-401-038-003



Пружина  
PPL-401-005-003