


401

PPI-401-042

*Cartridge /
Plunger Positioner 70
(P-TG190-7)*

Cartridge /
Plunger Positioner 70
(P-TG190-7)
PPl-401-042



401



PPl-401-042

Cartridge /
Plunger Positioner 70
(P-TG190-7)
PPl-401-042

401



*Cartridge /
Plunger Positioner 70
(P-TG190-7)
PPl-401-042*

401

PPl-401-042



*Cartridge /
Plunger Positioner 70
(P-TG190-7)
Specification*

<i>N° pos.</i>	<i>Code</i>	<i>Name</i>	<i>Qty</i>
<i>Parts:</i>			
1	PPl-401-042-001	Main body	1
2	PPl-401-042-002	Bushing	1
3	PPl-401-042-003	Spring	1
4	Screw UNC3/8"-16x2 1/4" DIN 912		4



PPl-401-042

Cartridge /
Plunger Positioner 70
(P-TG190-7)
PPL-401-042



401



Main body
PPL-401-042-001



Bushing
PPL-401-042-002



Spring
PPL-401-042-003