


401

PPI-401-043

*Cartridge /
Plunger Positioner 90
(EM5-62-3052-5-90)*

Cartridge /
Plunger Positioner 90
(EM5-62-3052-5-90)
PPL-401-043


401



PPL-401-043

Cartridge /
Plunger Positioner 90
(EM5-62-3052-5-90)
PPL-401-043

401



PPL-401-043

*Cartridge /
Plunger Positioner 90
(EM5-62-3052-5-90)
PPL-401-043*

401

PPL-401-043

*Cartridge /
Plunger Positioner 90
(EM5-62-3052-5-90)*

Specification

<i>Nº pos.</i>	<i>Code</i>	<i>Name</i>	<i>Qty</i>
----------------	-------------	-------------	------------



Parts:

<i>1</i>	<i>PPL-401-016-003</i>	<i>Spring retainer</i>	<i>1</i>
<i>2</i>	<i>PPL-401-016-005</i>	<i>Screw</i>	<i>1</i>
<i>3</i>	<i>PPL-401-016-006</i>	<i>Adapter</i>	<i>1</i>
<i>4</i>	<i>PPL-401-016-007</i>	<i>Spring</i>	<i>1</i>
<i>5</i>	<i>PPL-401-016-008</i>	<i>Split ring</i>	<i>2</i>
<i>6</i>	<i>PPL-401-023-002</i>	<i>Sleeve</i>	<i>1</i>
<i>7</i>	<i>PPL-401-043-001</i>	<i>Main body</i>	<i>1</i>



PPL-401-043

Cartridge /
Plunger Positioner 90
(EM5-62-3052-5-90)
PPL-401-043



401



Main body
PPL-401-043-001






Sleeve
PPL-401-023-002





Spring retainer
PPL-401-016-003




PPL-401-043






Spring
PPL-401-016-007



Adapter
PPL-401-016-006



Split ring
PPL-401-016-008



Screw
PPL-401-016-005