


401

PP1-401-044

*Позиционер плунжера 83
(EM5-62-412-2-83)*

Позиционер плунжера 83
(EM5-62-412-2-83)
PPL-401-044



401



PPL-401-044

Позиционер плунжера 83
(EM5-62-412-2-83)
PPL-401-044

401



PPL-401-044

Позиционер плунжера 83
(EM5-62-412-2-83)
PPI-401-044

401

PPI-401-044

Позиционер плунжера 83
(EM5-62-412-2-83)




Спецификация

№ поз.	Шифр	Наименование	Кол-во
<i>Детали:</i>			
1	PPI-401-001-009	Кольцо дистанционное	1
2	PPI-401-001-010	Полукольцо	2
3	PPI-401-001-011	Адаптер	1
4	PPI-401-015-005	Пружина	1
5	PPI-401-044-001	Корпус картриджа	1
6	PPI-401-044-002	Гильза	1
7	PPI-401-044-003	Держатель пружины	1



PPI-401-044

Позиционер плунжера 83
(EM5-62-412-2-83)
PPL-401-044



401



Корпус картриджа
PPL-401-044-001



Гильза
PPL-401-044-002






Держатель пружины
PPL-401-044-003




PPL-401-044

Позиционер плунжера 83
(EM5-62-412-2-83)
PPL-401-044




401





Пружина
PPL-401-015-005



Адаптер
PPL-401-001-011



Полукольцо
PPL-401-001-010



Кольцо дистанционное
PPL-401-001-009

PPL-401-044