


401

PPI-401-006

*Cartridge /
Plunger Positioner 70
(62-404-9)*

Cartridge /
Plunger Positioner 70
(62-404-9)
PPL-401-006


401



PPL-401-006

Cartridge /
Plunger Positioner 70
(62-404-9)
PPL-401-006

401



PPL-401-006

*Cartridge /
Plunger Positioner 70
(62-404-9)
PPL-401-006*

401

PPL-401-006

*Cartridge /
Plunger Positioner 70
(62-404-9)*

Specification

<i>Nº pos.</i>	<i>Code</i>	<i>Name</i>	<i>Qty</i>
----------------	-------------	-------------	------------

Parts:

<i>1</i>	<i>PPL-401-050-001</i>	<i>Main body</i>	<i>1</i>
<i>2</i>	<i>PPL-401-050-002</i>	<i>Bushing</i>	<i>1</i>
<i>3</i>	<i>PPL-401-050-003</i>	<i>Spring</i>	<i>1</i>
<i>4</i>	<i>PPL-401-050-004</i>	<i>Spring retainer</i>	<i>1</i>




Standard parts:

<i>5</i>	<i>Screw M6x10 DIN 912</i>	<i>2</i>
<i>6</i>	<i>Screw UNC3/8"-16x2" DIN 912</i>	<i>4</i>




PPL-401-006

Cartridge /
Plunger Positioner 70
(62-404-9)
PPL-401-006



401






Гильза
PPL-401-050-002



Корпус картриджа
PPL-401-050-001



Пружина
PPL-401-050-003



Держатель пружины
PPL-401-050-004

PPL-401-006