


*401*

*PPL-401-051*

*Cartridge /  
Plunger Positioner 70  
(A57-15-115)*

Cartridge /  
Plunger Positioner 70  
(A57-15-115)  
PPL-401-051



401



PPL-401-051

Cartridge /  
Plunger Positioner 70  
(A57-15-115)  
PPL-401-051

401



PPL-401-051

Cartridge /  
Plunger Positioner 70  
(A57-15-115)  
PPL-401-051

401

## PPL-401-051

Cartridge /  
Plunger Positioner 70  
(A57-15-115)

Specification

N° pos.	Code	Name	Qty
---------	------	------	-----

Сборочные единицы:

1	PPL-401-051-001	Cap assembly	1
---	-----------------	--------------	---

Parts:

2	PPL-401-051-002	Adapter	1
3	PPL-401-051-003	Casing	1
4	PPL-401-051-004	Spring retainer	1
5	PPL-401-051-005	Spring	1
6	PPL-401-051-006	Main body	1
7	PPL-401-051-007	Ring	1
8	PPL-401-051-008	Sleeve	1
9	PPL-401-051-009	Spring	1
10	PPL-401-051-010	Washer	1
11	PPL-401-051-011	Flange	1
12	PPL-401-051-012	Split ring	2
13	PPL-401-051-013	Tube adapter	1




Standard parts:

14	Screw M10x50 DIN 912	4
15	Screw M5x8 DIN 912	6
16	Spring pin $\Phi$ 3x12 DIN 1481	1



PPL-401-051

Cartridge /  
Plunger Positioner 70  
(A57-15-115)  
PPL-401-051



401



Casing  
PPL-401-051-003



Spring retainer  
PPL-401-051-004





Main body  
PPL-401-051-006



PPL-401-051

Cartridge /  
Plunger Positioner 70  
(A57-15-115)  
PPL-401-051




401



Ring  
PPL-401-051-007



Sleeve  
PPL-401-051-008






Spring  
PPL-401-051-005




PPL-401-051

Cartridge /  
Plunger Positioner 70  
(A57-15-115)  
PPL-401-051




401






Spring  
PPL-401-051-009



Washer  
PPL-401-051-010



Flange  
PPL-401-051-011






Split ring  
PPL-401-051-012




PPL-401-051

Cartridge /  
Plunger Positioner 70  
(A57-15-115)  
PPL-401-051

401



Adapter  
PPL-401-051-002




Tube adapter  
PPL-401-051-013

PPL-401-051

Cap assembly  
PPL-401-051-001

401



*PPL-401-051-001*

*Cap assembly*

*Specification*

<i>N° pos.</i>	<i>Code</i>	<i>Name</i>	<i>Qty</i>
----------------	-------------	-------------	------------


*Parts:*

1	PPL-401-051-001-001	Cap	1
2	PPL-401-051-001-002	Washer	1
3	PPL-401-051-001-003	Screw	1
4	PPL-401-051-001-004	Plug	1
5	PPL-401-051-001-005	Spring	1



*Standard parts:*

6	pin 6Гx50 ГОСТ 3128-70		1
---	------------------------	--	---



PPL-401-051-001






Cap  
PPI-401-051-001-001





Washer  
PPI-401-051-001-002



Spring  
PPI-401-051-001-005



Screw  
PPI-401-051-001-003



Plug  
PPI-401-051-001-004