


*401*

*PPI-401-054*

*Cartridge /  
Plunger Positioner 70  
(A57-15-68)*

Cartridge /  
Plunger Positioner 70  
(A57-15-68)  
PPL-401-054



401



PPL-401-054

Cartridge /  
Plunger Positioner 70  
(A57-15-68)  
PPI-401-054

401



Cartridge /  
Plunger Positioner 70  
(A57-15-68)  
PPL-401-054

401

## PPL-401-054

Cartridge /  
Plunger Positioner 70  
(A57-15-68)

Specification

Nº pos.	Code	Name	Qty
---------	------	------	-----

Parts:

1	PPL-401-051-004	Spring retainer	1
2	PPL-401-051-010	Washer	1
3	PPL-401-051-012	Split ring	2
4	PPL-401-051-013	Tube adapter	1
5	PPL-401-054-001	Adapter	1
6	PPL-401-054-002	Cap	1
7	PPL-401-054-003	Casing	1
8	PPL-401-054-004	Spring	1
9	PPL-401-054-005	Main body	1
10	PPL-401-054-006	Ring	1
11	PPL-401-054-007	Split ring	2
12	PPL-401-054-008	Spring	1
13	PPL-401-054-009	Bolt adapter	1




Standard parts:

14	pin 10Гx60 ГОСТ 3128-70	1
15	Screw M10x50 DIN 912	4
16	Screw M4x5 ГОСТ 11074-93	1
17	Screw M5x8 DIN 912	6
18	Spring pin $\Phi$ 3x12 DIN 1481	1



PPL-401-054

Cartridge /  
Plunger Positioner 70  
(A57-15-68)  
PPL-401-054




401



Casing  
PPL-401-054-003





Spring retainer  
PPL-401-051-004






Spring  
PPL-401-054-004

Cartridge /  
Plunger Positioner 70  
(A57-15-68)  
PPl-401-054




401



Main body  
PPl-401-054-005



Ring  
PPl-401-054-006






Bolt adapter  
PPl-401-054-009



PPl-401-054

Cartridge /  
Plunger Positioner 70  
(A57-15-68)  
PPL-401-054




401






Split ring  
PPL-401-054-007



Spring  
PPL-401-054-008



Washer  
PPL-401-051-010






Split ring  
PPL-401-051-012




PPL-401-054

Cartridge /  
Plunger Positioner 70  
(A57-15-68)  
PPL-401-054



401



Adapter  
PPL-401-054-001



Tube adapter  
PPL-401-051-013



Cap  
PPL-401-054-002

PPL-401-054