


401

PPI-401-056

*Cartridge /
Plunger Positioner 70
(06850475-00)*

Cartridge /
Plunger Positioner 70
(06850475-00)
PPL-401-056



401



PPL-401-056

Cartridge /
Plunger Positioner 70
(06850475-00)
PPL-401-056

401



*Cartridge /
Plunger Positioner 70
(06850475-00)
PPL-401-056*

401

PPL-401-056

*Cartridge /
Plunger Positioner 70
(06850475-00)*

Specification

<i>Nº pos.</i>	<i>Code</i>	<i>Name</i>	<i>Qty</i>
----------------	-------------	-------------	------------

Parts:

<i>1</i>	<i>PPL-401-056-001</i>	<i>Ring</i>	<i>1</i>
<i>2</i>	<i>PPL-401-056-002</i>	<i>Spring</i>	<i>1</i>
<i>3</i>	<i>PPL-401-056-003</i>	<i>Bushing</i>	<i>1</i>
<i>4</i>	<i>PPL-401-056-004</i>	<i>Flange</i>	<i>1</i>



Standard parts:

<i>5</i>	<i>Screw M5x6 ГОСТ 11074-93</i>		<i>2</i>
----------	---------------------------------	--	----------



PPL-401-056

Cartridge /
Plunger Positioner 70
(06850475-00)
PPL-401-056



401





Ring
PPL-401-056-001



Spring
PPL-401-056-002



Bushing
PPL-401-056-003



Flange
PPL-401-056-004