


401

PPI-401-058


*Позиционер плунжера
(06850405)*

Позиционер плунжера
(06850405)
PPL-401-058

401



PPL-401-058



PPL-401-058

Позиционер плунжера
(06850405)

Спецификация

№ поз.	Шифр	Наименование	Кол-во
--------	------	--------------	--------

Сборочные единицы:



1	PPL-401-058-001	Корпус в сборе	1
---	-----------------	----------------	---

Детали:



2	PPL-401-010-005	Кольцо	1
3	PPL-401-031-002	Пружина	1
4	PPL-401-058-002	Стакан	1
5	PPL-401-058-003	Корпус картриджа	1
6	PPL-401-058-004	Фланец	1
7	PPL-401-058-005	Втулка	1
8	PPL-401-058-006	Адаптер	1
9	PPL-401-058-007	Спец. винт	1

Стандартные изделия:


10	Винт M8x30 ISO 7380	4
11	Кольцо A90 ГОСТ 13941-86	1




Корпус картриджа
PPL-401-058-003





Пружина
PPL-401-031-002




Фланец
PPL-401-058-004



Кольцо
PPI-401-010-005




Втулка
PPI-401-058-005





Адаптер
PPI-401-058-006

Позиционер плунжера
(06850405)
PPL-401-058

401




Стакан
PPL-401-058-002



Спец. винт
PPL-401-058-007

PPL-401-058



PPL-401-058-001

Корпус в сборе

Спецификация



№ поз.	Шифр	Наименование	Кол-во
--------	------	--------------	--------

Детали:


1	PPL-401-031-003-001	Корпус картриджа	1
2	PPL-401-031-003-002	Кольцо	1
3	PPL-401-031-003-005	Кольцо	1
4	PPL-401-046-002	Стакан	1
5	PPL-401-046-003	Пружина	1
6	PPL-401-058-001-001	Кольцо	1

Стандартные изделия:


7	Кольцо стопорное В 60 DIN 7993	1
---	--------------------------------	---





Корпус картриджа
PPL-401-031-003-001



Кольцо
PPL-401-031-003-002





Кольцо
PPL-401-058-001-001






Стакан

PPL-401-046-002



Кольцо

PPL-401-031-003-005



Пружина

PPL-401-046-003