


401

DGK-401-028

Neck ring Holder
(DGK-0625-E2-7-82)
6 1/4"

Neck ring Holder
(DGK-0625-E2-7-82)
6 1/4"
DGK-401-028



401



DGK-401-028

Neck ring Holder
(DGK-0625-E2-7-82)
6 1/4"
DGK-401-028

401



DGK-401-028

Neck ring Holder
(DGK-0625-E2-7-82)
6 1/4"
DGK-401-028

401

DGK-401-028

Neck ring Holder
(DGK-0625-E2-7-82)
6 1/4"
Specification

Nº pos.	Code	Name	Qty
---------	------	------	-----

Сборочные единицы:

1	DGK-401-004-003	Lock assembly	4
---	-----------------	---------------	---




Parts:

2	DGK-401-001-004	Insert	4
3	DGK-401-002-003	Leaf spring	4
4	DGK-401-028-001	Right rack	1
5	DGK-401-028-002	Left rack	1




DGK-401-028

Neck ring Holder
(DGK-0625-E2-7-82)
6 1/4"
DGK-401-028




401





Right rack
DGK-401-028-001




Left rack
DGK-401-028-002



Insert
DGK-401-001-004



Leaf spring
DGK-401-002-003



DGK-401-004-003

Lock assembly

Specification



Nº pos.	Code	Name	Qty
---------	------	------	-----

Parts:




1	DGK-401-001-001-002	Screw	1
2	DGK-401-003-003-003	Spring	1
3	DGK-401-004-003-001	Axis	1

Standard parts:

4	Spring pin ϕ 3x18 DIN 1481	1
---	---------------------------------	---





Axis
DGK-401-004-003-001



Screw
DGK-401-001-001-002

DGK-401-004-003



Spring
DGK-401-003-003-003